

410 Training Material

Air Conditioning Configuration & Model Information

This training material provides an overview of air conditioning configurations by floorplan, including unit types, heat pump options, and standard operating information for Plant 410 models.

Use this guide to quickly reference model differences and explain system capabilities to dealers and customers.



Every model gets 3 A/C units as std, and will all run at same time, but don't start all at once...as in-rush current spikes...

FOR FLAT ROOF FLOORPLANS:

(377DS, 388FKH, 389FLH, 393RL, 394RKL, 395FKL, 396FLL) see below

2 LOW PROFILE COLEMAN MACH 8 SERIES 15K

+

1 LOW PROFILE COLEMAN MACH 8 SERIES WITH HEATPUMP 15K



Every model gets 3 A/C units as standard, and will all run at same time, but don't start all at once...as in-rush current spikes...

FOR NON-FLAT ROOF FLOORPLANS:

383RLH , 384RKH , 379MBL: see below

2 LOW PROFILE COLEMAN MACH 8 SERIES 15K (one with heat pump)

+

1 STANDARD PROFILE COLEMAN MACH 10 SERIES